

GTR DIFFERENTIALS

Some of the differentials you have received may or may not have grease already in them.

Be sure to pump each differential full of grease until you see grease coming out of it.

You can do this with the differential in or out of the unit.

We recommend you using a high temperature grease.

